
ADJUSTMENT ON GAME PC BOARD (G25 00533A VOLFIED)

CONNECTOR



☆ THE CONTROL OF THIS GAME USES ONE 4-WAY LEVER AND ONE BUTTON.

GND GND +5V	A B	1	GND
	B		ן עווט ו
+57		2	GND
	С	3	+5V
+5V	D	4	+57
-5V	E	5	-57
+12V	F	6	+12V (+13V)
POST	H	7	POST
COIN COUNTER (B)	J	8	COIN COUNTER (A)
COIN LOCKOUT (B)	K	9	COIN LOCKOUT (A)
SPEAKER (-)	L	10	SPEAKER (+)
	M	11	
VIDEO G	И	12	VIDEO R
VIDEO SYNC	P	13	VIDEO B
SERVICE SW	R	14	VIDEO GND
TILT SW	S	15	
(COIN B)	Ţ	16	COIN A
2P SELECT	U	17	1P SELECT
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P LASER-CUTTER	Z	22	1P LASER-CUTTER
	а	23	
	b	24	
	С	25	
	d	26	
GND	е	27	GND
GND	f	28	GND

NOTE: AFTER CHANGING THE SETTINGS OF DIP SWITCHES, TURN THE POWER OFF.

SETTING OF DIP SWITCH A

(*) : FACTORY SETTINGS

SETTINGS	POSITIONS	1	2	3	4	5	6	7	8
GAME STYLE	TABLE	OFF					*		
GAME STILE	UPLIGHT	ON	1						
SCREEN ROTATION	* NORMAL		OFF	1					
SCREEN ROTATION	REVERSE	1	ON	1					
TEST MODE	* NORMAL GAME			OFF	1	<u> </u>			
TEST MODE	TEST MODE	1.		ON		ļ			
ATTRACT SOUND	* WITH	OFF			OFF				
ATTACT SOUND	WITHOUT				ON	1			
	* 1 COIN 1 PLAY					OFF	OFF		
PLAY PRICING	2 COINS 1 PLAY]				ON	011		
COIN A	3 COINS 1 PLAY				OFF	ON			
	4 COINS 1 PLAY	ON				I ON			
	* 1 COIN 2 PLAYS							OFF	OFF
.AY PRICING	1 COIN 3 PLAYS							ON	011
COIN B	1 COIN 4 PLAYS							OFF	ON
	1 COIN 6 PLAYS							ON	1 011

♦ SETTING OF DIP SWITCH B

POSITIONS	SETTINGS	1	2	3	4	5	6	7	8
GAME DIFFICULTY EASY(A)→	* RANK B	OFF	OFF				************		
	RANK A	ON	N OFF			İ			
DIFFICULT (D)	RANK C	OFF	ON	1					
DITTICULI (D)	RANK D	ON	7 08						
BONUS POINTS	* 20K/40K/120K/480K/2,400K PTS.			OFF	055				
(1 UP)	50K/150K/600K/3,000K PTS.			ON	OFF	l		OFF	
(K=1,000PTS.)	70K/280K/1,400K PTS.			OFF	T _{ov}				
(K=1,000P13.)	100K/500K PTS.				ON				
	* 3					OFF	0.55		
NUMBER OF	4					ON	OFF		
PLAYERS	5	5				OFF	0.11		
	6	6				ON	ON		
EXPRANATION FOR	JAPANESE					•	•		OFF
GAME RULES	* ENGLISH								ON

"VOLFIED" SETTINGS OF DIP SWs (for other than North America)

DIP SW-A:

	DTI DM-U	•						-	-	
1	Settings	Positions	15	2	3	a,	. 5	: 5	.7	B
	Game Style	Table. Upright	OFF ON				•	•		
	Screen Inversion	Normal Game Inversion		OFF ON			•	,	,	
	Test Mode	Normal Game Test Mode			DEF ON		. ;	• .'	·. :	
	Attract Sounds	Without		. 7		OFF		11	, , ,	
	Play Pricing Coin Slot - A	L Coin - 1 Play 2 Coins - 1 Play 3 Coins - 4 Play 4 Coins - 1 Play		٠.	,	•	OFF OH OFF	OFF.		
	Play Pricing Coin Slot-B	1 Coin - 2 Plays. 1 Coin - 3 Plays. 1 Coin - 4 Plays. 1 Coin - 6 Plays.			1000 1000 1000 1000	,			OFF.	OFF OW

DIP SW-B:

Settings	Positions	1	2	3	4	5	. 6	7	8
	Rank-B	UFF 9N:	OFF		:				
Difficulty Levels	1 - C + - D	OFF ON	י אט				,. ,		
Bouns	Normal Easy:			OFF ON	OFF				
Points (See Note".)	Hardert Hardert			OFF ON	· 0N·			:,=	
Number of - Players	3 ·		4			OFF	-OFF		
Players	5					OFF	-ÒĶ		
(Spare)				***	•				/
Attract	Jopanese English	.			- Andrew			_	ōFF:


* Factory Settings: all "OFF" Positions

Note: Details of Bonus Points

·		2	3	1.	\$
EASY	25,000	40,000	129900	480,000	2400,000
HORMAL	50000	130,000	600,000	3000000	
HARD	70,000	280000	dedana		
HARDEST	100,000	200000	_	7 ,	



① ENCLOSE IT BY USING THE LASER CUITER BUTTON AND




② DURING MOVING ON THE GREEN "SHIELD LINE" · · · (BURRIER IS ON)

DURING THE PERIOD FROM THE BEGINNING OF DRAWING THE RED LASER LINE TO THE COMPLETION OF ENCLOSING · · · (BARRIER IS OFF)




- WHEN THE BARRIER IS OFF. IF AN ENEMY TOUCHES THE PLAYER'S MACHINE OR THE RED LASER LINE, THE PLAYER'S MACHINE EXPLODES.



·LASER: THE PLAYER





·CLASH: THE FOLLOWER
ARE SWEPT
AWAY!

POWER: THE ENERGY
STOPS
DECREASING
FOR A LIMITED
TIME!!





CUT OFF THE ENERGY FIELD 80% OR MORE!!

